TRUCKS OVER TONS MUST ENTER WEIGH STATION NEXT RIGHT

R13-1 Weigh Station

OVER TONS MUST ENTER WEIGH STATION NEXT RIGHT

R13-1 (white on black)
Weigh Station