

## HOV ONLY

## OR MORE PERSONS PER VEHICLE

R3-13 HOV Definition (Overhead)